



Smart Control point Manual



Smart Kit Operation Instructions

- *Running mode*

After turning on the power, the device switches to the running mode.

The indicator shows the number of the current scenario. The circular scale and indicator displays the time until starting this scenario. Pressing the button changes the gaming scenario. "New Game" command from any device (medkit, remote pro, universal remote etc) interrupts the current game and starts a new countdown. "Start Game" command immediately starts or restarts the current scenario.

- *Administrative mode*

To start administrative mode, turn on the power while pressing and holding the administrator button. After entering the mode, you can change the scenario's settings both from IR-base, and directly on the device.

All setting has their number names.
 From P01 to P03 – names of common settings.
 From P11 to P12 – names of first scenario settings
 From P21 to P26 – names of second scenario settings
 From P31 to P37 – names of third scenario settings

Full table of settings is below.

Number name	Description	Range	Unit of measure
P 01	Number of scenario	1 - 3	
P 02	Start delay	1-59:59	Seconds
P 03	Language	0-1	
1 scenario			
P 11	Time to hold	10-59:59	Seconds
P 12	Delay before emitting command that subtracts health hit points	0-9	Seconds

2 scenario			
P 21	Time to capture	10-59:59	Seconds
P 22	Delay before emitting command that subtracts health hit points	0-9	Seconds
P 23	Time to hold	1-59:59	Minutes
P 24	Capturing speed acceleration	0.01-99.99	0.01 seconds
P 25	Delay before emitting command that adds health hit points	0-59:59	Seconds
P 26	Number of «add health hit points» commands	1-30	
3 scenario			
P 31	Strength points	1-9999	
P 32	Team that holds the point	0-4	
P 33	Recovering delay	1-59:59	Seconds
P 34	Recovering speed	1-9999	1 point/second
P 35	Delay before emitting command that subtracts health hit points	0-9	Seconds
P 36	Delay before emitting command that adds health hit points	0-59:59	Seconds
P 37	Number of «add health hit points» commands	1-30	
Saving			
St	Save changes		

We will be happy to answer all your questions by e-mail sales@LaserWar.us or you can visit our website <http://www.LaseWar.US>